

## 26800 Wiring List

File Name: S2-26800-DemoPgm

<u>SWITCHES</u>	<u>FREQUENCY</u>	<u>POWER INPUT</u>	<u>ANALOG OUTPUTS</u>
SW1:	EXC: <b>WD EXCITATION</b>	PWR+: <b>T/RH +PWR</b>	OUT1:
SW2:	EXC:	PWR-: <b>T/RH PWR REF</b>	OUT2:
REF	FREQ1: <b>WS SIGNAL INPUT</b>	EARTH:	REF:
SW3:	FREQ2:		OUT3:
SW4:	REF:	<u>RS-232</u>	OUT4:
REF:	FREQ3:	TX:	REF:
	FREQ4:	RX:	
<u>ANALOG INPUTS (9-16)</u>	REF: <b>WS REFERENCE</b>	REF:	
VIN9:			
VIN10:	<u>ANALOG INPUTS (1-8)</u>	<u>RS-485</u>	
REF:	VIN1: <b>WD SIGNAL INPUT</b>	A1:	
VIN11:	VIN2:	B1:	
VIN12:	REF: <b>SHIELD</b>	A2:	
REF:	VIN3:	B2:	
VIN13:	VIN4:	REF:	
VIN14:	REF:		
REF:	VIN5: <b>TEMP SIGNAL</b>		
VIN15:	VIN6: <b>SIGNAL REF</b>		
VIN16:	REF:		
REF:	VIN7: <b>RH SIGNAL</b>		
	VIN8: <b>SIGNAL REF</b>		
	REF:		